

Seatbelt Cam buckle threading:

First thread on the triglide keeper:

Identify the top of the webbing by placing the sewn under portion of the seatbelt face down.

Position the triglide with the flat side down.

Thread the top side of the webbing up through the triglide, over the top rib and down through the other side.

Then thread the cam buckle on:

Go up through the first slot

Down through the second slot

Up through the slot nearest the edge

Around the edge

Return along the same path:

Up through the second slot and down through the first slot

Continue following the original path back through the triglide.

Remove slack by gathering both layers and tugging side to side.

