

Packing Sand Rider in the bag

1. Place the bag on the floor with the Sand Rider logo facing up. Open the bag folding the top flap backwards.
2. Place one wheel upright at the back of the bag.
3. Position the seat base with the seat down and axle up as shown. Place foam collar on brake knob (if equipped.)
4. Lay the remaining wheel flat on top of the seat base.

5. Turn the front fork upside down and place it on top of the wheel. Place small parts bag (containing axles, pins and clamps) and both armrests on the footrest pocket. Note: If your air carrier has a 50 pound weight limit, consider packing the armrests in your carry on.
6. Lay the backrest on the front fork. Zip bag. Cinch straps and wrap any excess strap around the cinched strap. If bag is difficult to zip completely, stand upright and shake firmly. If cinch strap buckles are removed, rethread as shown.

